Page 1 of 7 SVANGE2442R - Specification Sheet

SVANGE 2442R LED Medicine Cabinet - Specification Sheet

Features

- Dimmable LED task lighting
- Integrated touch sensor control with memory
- Energy efficient LED lighting 5000K
- 3250 Lumens
- CRI 90+
- Integrated Defogger

Construction

- Quality polished edge mirror
- Single phase wire installation
- 5 MM Silver Backed Copper Free
- Installation Either Surface Mount
- (Side Mirror Trim Panels included) or Recessed
- Includes installation hardware

Codes/Standards Applicable


- Conforms to UL Std. 962
- Cert. to CSA Std. C22.2 No.250.0-08
- ETL Intertek 5004931

Electrical System

- 120Vac, 60Hz, 55W
- Electric Current: 0.46A
- Wattage: 55W

Model

SVANGE 2442R Right Swinging Door







- Perfomance Requirments: Contains the required
- Supervisory Circiut with the Auto-Monitoring Function as noted by UL 1310
- Input Voltage: Min 112Vac, Nom 125Vac, Max 137Vac
- Frequency:60Hz
- Front Receptacle Current: 102-132Vac Nominal 15A
- USB Output Current:5VDC Nominal 4A






CABINET CONFIGURATION












SURFACE MOUNT



These measurements are for reference, for best results we suggest you measure actual product as small variations in size are possible




Wall ۲ Cut Recess **Recessed Cabinet** Ε. FRONT ВАСК A. С. Optional Electrical Cord Outlets D. B. FRONT & BACKS MODEL В С D Е SVANGE2442R 23 3-7/8 42 41-1/2 24

RECESSED MOUNT



RECESS INSTALLATION OPTIONAL ELECTRICAL CORD LOCATIONS





ELECTRICAL CORD LOCATIONS

MODEL	MODEL A		С	D	
SVANGE2442R	1-1/2	1-1/8	1-3/8	11-1/4	

These measurements are for reference, for best results we suggest you measure actual product as small variations in size are possible








DOOR & CABINET

MODEL	А	В	С	D	E	F	G
SVANGE2442R	7/8	3-7/8	4-3/4	18	3/8	5-1/4	11-1/4



INTERIOR CABINET

MODEL	А	В	С	D	E	F	G	н	I
SVANGE2442R	3-3/4	5-5/8	1-1/4	38-1/4	2-1/4	22-1/2	2-3/8	3/8	3-5/8

These measurements are for reference, for best results we suggest you measure actual product as small variations in size are possible